


# FOR USE WITH 240VAC HEATERS



NOTE: MAX 32-AMPS PER BREAKER

# FOR USE WITH 208VAC HEATERS




HOUR MAX TIMER

NOT COMPATIBLE WITH INF CONTROLS DESIGNED FOR USE WITH ENCLOSED 4


HOUR MAX TIMER


240VAC SINGLE PHASE INPUT





NOTE: MAX 32-AMPS PER BREAKER

CONTACT INFRATECH FOR A CUSTOM CONTACTOR PANEL.









### FOR USE WITH 240VAC HEATERS

#### 240VAC SINGLE PHASE INPUT

NOTES:


NOTES:

DESIGNED FOR USE WITH ENCLOSED 4 HOUR MAX TIMER ORANGE JUMPER INCLUDED FOR TYING D1 & D2 TOGETHER AT TERMINAL BLOCK IF THAT IS THE DESIRED ZONING.

NOT COMPATIBLE WITH INF CONTROLS DESIGNED FOR USE WITH ENCLOSED 4

ORANGE JUMPER INCLUDED FOR TYING D1 & D2 TOGETHER AT TERMINAL BLOCK IF THAT IS THE DESIRED ZONING.


HOUR MAX TIMER



**NOTE: MAX 32-AMPS PER BREAKER** 

# FOR USE WITH 208VAC HEATERS





**NOTE: MAX 32-AMPS PER BREAKER** 

CONTACT INFRATECH FOR A CUSTOM CONTACTOR PANEL.

