

IMPORTANT- PLEASE READ PRIOR TO INSTALLATION

Correct Placement for Home Management

Home Management Relay Panel Placement

- Surface Mount in a well ventilated area.
- Louvers are located on the top left and the bottom right side of the panel. It is suggested the power be brought in through the top or bottom of the panel (not from the back).
- Minimum clearance is 12" on EACH side. Additional clearance will be needed if placed in a poorly ventilated area.
- NEMA 3R Enclosure.
- Must be accessible per National Electric Code (NEC).



For use in conjunction with your Home Management System

- Infratech's Home Management Control is compatible with top selling systems like Lutron™, Crestron™, Control 4™, Savant™, and others.
- Infratech's simple interface requires a 0-10V DC signal for streamlined installation and straightforward programming.

NOTE: Use of Competitor Heaters/Accessories with Infratech Controls may Void the Infratech Warranty

