Inital Panel Setup

To calculate amp draw of a heater: Wattage/Voltage

EX: WD6024 6000W/240V = 25A For SSR panels and Home Management Panels, can use low voltage wire or CAT5/CAT6 for control wiring.

For Universal Panel, must use 120 VAC wiring.



